

How to Reload firmware on LoopMeeting LM-1052T/1056T with Android 10 and 11

1. Install driver support for LoopMeeting device

Download, unzip and install the Android RK device drivers https://loopmeeting.no/firmware/LMDriver.zip

After installation, please reboot your computer.

2. Download and unrar/unzip tools and firmware

Download the Firmware loading tool and unzip it to a directory. https://loopmeeting.no/firmware/rktool.zip

Download the correct Firmware version based on the production year/month. and unrar the file. You will see the correct production month/year on the serial number sticker on the backside of the panel.

It is important to select the correct file.

December 2021	https://loopmeeting.no/firmware/des21.rar
January 2022	https://loopmeeting.no/firmware/jan22.rar
April 2022	https://loopmeeting.no/firmware/apr22.rar
May 2022	https://loopmeeting.no/firmware/mai22.rar
June 2022	https://loopmeeting.no/firmware/jun22.rar
September 2022	https://loopmeeting.no/firmware/sept22.rar
December 2022	https://loopmeeting.no/firmware/des22.rar
February 2023	https://loopmeeting.no/firmware/feb23.rar
April 2023	https://loopmeeting.no/firmware/apr23.rar
Oct 2023	https://loopmeeting.no/firmware/oct23.zip
Nov 2023	https://loopmeeting.no/firmware/nov23.zip



3. Load firmware to Loopmeeting panel

Connect a USB cable to your computer and to the micro USB port on the device Connect power while holding the "reset" button pressed with a paperclip or similar.

The reset button is just beside the LAN port in a small hole

Hold it for a few seconds then release the button (The device will stay black)

Start Android Tool

Check that you have «Found One LOADER Device" in the bottom line

I V 0x00000000 Loader \rockdev\Image~rk3399\Minil 2 V 0x00000000 Parameter \rockdev\Image~rk3399\param 3 V 0x00000000 Uboot \rockdev\Image~rk3399\u00et 4 V 0x00000000 Uboot \rockdev\Image~rk3399\trust 5 V 0x00000000 Misc \rockdev\Image~rk3399\misc. 6 V 0x00024000 Dtbo \rockdev\Image~rk3399\dtbo. 7 V 0x00026000 vbmeta \rockdev\Image~rk3399\vbmeta	eter.txt img img
2 V 0x00000000 Parameter \rockdev\Imagerk3399\param 3 V 0x00004000 Uboot \rockdev\Imagerk3399\uboot 4 V 0x00006000 trust \rockdev\Imagerk3399\trust 5 V 0x00008000 Misc \rockdev\Imagerk3399\misc. 6 V 0x00024000 Dtbo \rockdev\Imagerk3399\dtbo. 7 V 0x00026000 vbmeta \rockdev\Imagerk3399\vbmet	eter.txt .img .img
3 V 0x00004000 Uboot \rockdev\Image=rk3399\uboot 4 V 0x00006000 trust \rockdev\Image=rk3399\trust 5 V 0x00008000 Misc \rockdev\Image=rk3399\misc. 6 V 0x00024000 Dtbo \rockdev\Image=rk3399\dtbo. 7 V 0x00026000 vbmeta \rockdev\Image=rk3399\vbmeta	img img
4 ✓ 0x00006000 trust \rockdev\Image¬rk3399\trust 5 ✓ 0x00008000 Misc \rockdev\Image¬rk3399\misc. 6 ✓ 0x00024000 Dtbo \rockdev\Image¬rk3399\dtbo. 7 ✓ 0x00026000 vbmeta \rockdev\Image¬rk3399\vbmet	img
5 V 0x00008000 Misc \rockdev\Image-rk3399\misc. 6 V 0x00024000 Dtbo \rockdev\Image-rk3399\dtbo. 7 V 0x00026000 vbmeta \rockdev\Image-rk3399\vbmeta	
6	img
7 🔽 0x00026000 vbmeta\rockdev\Image=rk3399\vbmet	img
	a.img
8 🔽 0x00026800 Boot\rockdev\Image=rk3399\boot.	img
9 🔽 0x00036800 Recovery\rockdev\Image=rk3399\recov	ery.img
10 🔽 0x00190800 System\rockdev\Image=rk3399\syste	n.img
11 🔽 0x00698800 Vendor\rockdev\Image=rk3399\vendo	r.img
12 🔽 0x00798800 0em\rockdev\Image=rk3399\oem.i	ng
	4
order: Run Switch Dev Partition	Clear

Select «Upgrade Firmware» in top menu

ownload Image	Upgrade Fi	rmware Adva	nced Function		
Firmware	Upgrade	Switch	EraseFlash		
Fw Ver:		Loader Ve	er:	Chip Tofo	
Firmware:					
					1
	Fou	nd One	LOADER I	Device	



Select "Firmware" in the menu.

And browse/select the unzipped file you downloaded. (It will take a few seconds for it to load)

Download Image	Upgrade Fi	rmware Adv	anced Function		
Firmware	pgrade	Switch	EraseFlash		
Fw Ver:		Loader V	/er:	Chip Tufo	
Firmware:					
	Fou	nd One	LOADER	Device	

Then select menuitem "Upgrade" This operation will take a few minutes.

Download Image	Upgrade Firmware Advanced Function
Firmware	Upgrade Switch EraseFlash
Fw Ver:	a. 0. 00 Loader Ver: 2. 58 Chip RK32 Thfo
Firmware:	C:\Privat\Firmware = LM and LS\ELC\Firmware\LM-1052T\Des-2021
	Found One LOADER Device

After the procedure is done LoopMeeting app will appear asking you to enter the license key. (If you do not have the license key, please contact <u>info@loop24.no</u> and provide the serial number for the device.)

Please Update App before entering the License key and connect it to O365/Exchange/Google/LoopBooking environment.

This is done by selecting "Demo Mode" when the panel asks for License key. Then select "Update App" and the panel will download and install the latest version.

If this fails, use option 4 as described in this link. <u>https://loop24.no/loopmeeting/app-update/</u>