

User Manual

LoopSign Player Application
The APK can be installed on Android 6.0 and above
(Some 5.1 versions might work)

Make sure you have the latest version installed:
<https://loop24.no/lsp.zip>

When the unit has started (The first time) it will by default show the config screen

Set the LoopSign URL you want to use.

Start Url

https://play.loopsign.eu/app/20/lsp

Select when daily reboot is initiated.

Reboot at

00:00

Select how often it will refresh the URL, 2 hours recommended

Refresh at

Never

Press here to change PIN code

Pin

Optionally enable Proxy server

Proxy

Enable

Host

Port

When you are done, press here to launch URL

LoopSign Player version 2.0.27
LoopSign Player is intended for use with Loop24 products
<http://loop24.no>
Loop24 AS
All rights reserved




CHECK FOR UPDATE

To enter this settings page from full screen LoopSign Player
Click top left corner and enter pincode

NEXT

If it does not start into the config screen, or you like to reconfigure, «click» upper left corner



Standard PIN code is 0000 (four zero numbers)

