


User Manual

LoopSign Player (Standalone LS-830)
LoopSign Player (Android on touchpanel)

Make sure you have the latest version installed: <https://sos.loopsign.eu/android/lsp.apk>



Startup

When the unit is connected to power it will automatically boot and start the URL player. (Depending on if it is a standalone player or touch screen), it might take up to 1 minute to autostart the player App - please be patient

When the unit has started (The first time) it will by default show the config screen

Press here and enter the URL the player should launch



Start Url

<https://loopsign.no/screen/20/mp4>

Select when daily reboot is performed



Reboot at

00:00

Select how often it will refresh the URL, 2 hours recommended



Refresh at

Never

Press here to change PIN code



Pin

Optionally enable Proxy server



Proxy

Enable

Host

Port

When you are done, press here to launch URL




LoopSign Player version 1.5
LoopSign Player is intended for use with Loop24 products
<http://loop24.no>
Loop24 AS
All rights reserved



To enter this settings page from full screen LoopSign Player
Click top left corner and enter pincode

NEXT

If it does not start into the config screen, or you like to reconfigure, «click» upper left corner



Standard PIN code is 0000 (four zero numbers)

